

# **PROJECT TITLE : REGENERATIVE BREAKING** **SYSTEM**

**GROUP NO.: – 58**

**GROUP MEMBER'S NAME :**

1. KISHAN KUMAR
2. MRIGANK KUMAR
3. PRIYANSHU KUMAR
4. HARSH KUMAR SINGH
5. SHREYAS AYUSH MINZ
6. ASHISH KUMAR
7. KAMAL RAJ RAWAT
8. ANIL DOODHWAL
9. DUSHYANT

**GUIDE NAME:**

**TUTOR:**

**Section :**


**Gr. No. : 58**


# INDEX

(All dimensions are in mm)

PART NO.	PART NAME	DIMENSIONS	PAGE NUMBER	QUANTITY	MATERIAL
	Isometric View		1 to 2		Mild steel
<b>1</b>	60 Teeth spur gear	Ø93X35	3	1	Mild steel
<b>2</b>	30 Teeth spur gear	Ø48X37	4	1	Mild steel
<b>3</b>	Handle	50X10; Ø20; Ø5	5	1	Plastic
<b>4</b>	Motor clamp	50X10; Ø20; Ø5	6	2	Plastic
<b>5</b>	Drum	Ø110X50	7	1	Mild steel
<b>6</b>	Drum Break	Ø24X22; Ø4X30	8	2	Mild steel
<b>7</b>	Shaft	Ø12.7X100L	9	2	Mild steel
<b>8</b>	Base Plate	150X260X3L	10	1	Mild steel
<b>9</b>	Support1	200X50X5L; 12.7; Ø5	11	4	Mild steel
<b>10</b>	L- Plate	50X50 ; Ø5	12	5	Mild steel
<b>11</b>	Paddle	50x22x20	13	1	Mild steel
<b>12</b>	Large Plate	108.06X14X2; Ø14	14	2	Mild steel
<b>13</b>	Small Plate	43.22X14X2; Ø14	15	2	Mild steel
<b>14</b>	Nail	Ø4X10	16	1	Mild steel
<b>15</b>	Support2	250X50X 5	17	1	Mild steel



## **REGENERATIVE BREAKING SYSTEM:**





ALL DIMENSIONS ARE IN MM

LARGER GEAR




Scale 3:4

Quantity	=	1
Nos. of Teeth (N)	=	60
Module (M)	=	1.5
Outer diameter (OD)	=	$M (N + 2) = 93\text{mm}$
Rod diameter (ID)	=	12.7
Depth of cut	=	$2.157 \times M = 3.24\text{mm}$
Tap hole size	=	5.2 mm drill & ¼" tapping
Indexing calculation	=	$40 / N = 2/3$

ALL DIMENSIONS ARE IN MM

### SMALLER GEAR




Scale 2:1

Quantity	=	1
Nos. of Teeth (N)	=	30
Module (M)	=	1.5
Outer diameter (OD)	=	$M (N + 2) = 48$
Rod diameter (ID)	=	12.7
Depth of cut	=	$2.157 \times M = 3.24$
Tap hole size	=	5.2 mm drill & $\frac{1}{4}$ " tapping
Indexing calculation	=	$40 / N = 4/3$

ALL DIMENSIONS ARE IN MM


HANDLE



SCALE 1:1

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Plastic  
DIMENSIONS (mm):  
FLAT SIZE: 50X10  
CIRCULAR PART:  $\varnothing 20$   
HOLE CUT :  $\varnothing 5$

**CLAMP**



SCALE 2:1

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Plastic  
DIMENSIONS (mm):  
FLAT SIZE: 50X10  
CIRCULAR PART:  $\phi 20$   
HOLE CUT :  $\phi 5$



## LARGER DRUM





SCALE 1:2

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm):  
CIRCULAR PART:  $\varnothing 110 \times 50\text{L}$   
HOLE CUT :  $\varnothing 10$

DRUM BREAK





Scale 2:1

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL=  
Plastic  
DIMENSIONS (mm):  
CYLINDRICAL PART:  
ø24X22L  
ROD: ø4X30L


SHAFT



ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm): Ø12.7X100L

BASE PLATE




Scale 1:2

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm): 150X260X3L  
HOLE CUT: ø5


SUPPORT1



SCALE 1:2

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm): 200X50X5L  
HOLE CUT 1: ø12.7  
HOLE CUT 2: ø5


**L-PLATE**

SCALE 1:1

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm): 50X50  
HOLE CUT :  $\varnothing 5$

PADLE



Scale 2:1

ALL DIMENSIONS ARE IN MM


REQUIRED MATERIAL= Mild  
Steel  
DIMENSIONS (mm): 50x22x20

## LARGE PLATE

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild stell DIMENSIONS (mm): FLAT SIZE: 108.06X14X2 CIRCULAR EDGE: $\varnothing$ 14 HOLE CUT : $\varnothing$ 4
--




**SMALL PLATE**

Scale 2 :1

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm):  
FLAT SIZE: 43.22X14X2  
CIRCULAR EDGE:  $\varnothing 14$   
HOLE CUT :  $\varnothing 4$


**NAIL**

Scale 5:1

ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild  
Steel  
DIMENSIONS (mm):  $\varnothing 4 \times 10$   
HEXAGON FACE: 3.95

## SUPPORT2



ALL DIMENSIONS ARE IN MM

REQUIRED MATERIAL= Mild Steel  
DIMENSIONS (mm): 250X50X5L  
HOLE CUT 1:  $\varnothing$   
HOLE CUT 2:  $\varnothing$